Shark™

OWNER'S MANUAL
GUIDE DU PROPRIETAIRE

Model / Modde UV610
7.2 Volt DC

Cordless Sweeper
Balai Motoris Sans Fil



For information or assistance:
Pour plus d'information ou pour obtenir de l'assistance :
EURO-PRO Corporation
4400 Bois Franc
Ville St. Laurent, QC H4S **IA7**
Tel.: l-800-361 -4639
www.sharkhomecare.com

EURO-PRO™

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be observed, including the following

READ ALL INSTRUCTIONS BEFORE USING YOUR CORDLESS SWEEPER.

WARNING. To reduce the risk of fire, electrical shock, or injury:

1. Do not charge this unit outdoors.
2. Do not use outdoors or on wet surfaces.
3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
4. Use only as described in this manual. Use only manufacturer's recommended attachments.
5. Do not use with damaged cord or plug. Do not use cordless sweeper if it has been dropped. damaaed. left outdoors, or dropped in water. Return it to ***EURO-PRO*** Corporation for examination repair or adjustment.
6. Do not abuse the charger cord. Never carry the charger or base by the cord or yank to disconnect from an outlet; instead grasp the charger and pull to disconnect.
7. Keep charger cord away from heated surfaces.
8. This product includes rechargeable nickel cadmium batteries. Batteries must be recycled or disposed of properly. **Do not incinerate batteries or expose to high temperatures,** as they may explode.
9. Do not handle plug or apoliance with wet hands.
10. Do not put any'object into openings. Do not use with any opening Mocked; keep free of dust, lint! hair and anything that may reduce air flow.
11. Keep hair loose clothing, fingers, and all parts of body away from openings and moving parts.
12. Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
13. Do not attempt to change accessories while unit is running.
14. Use extra care when cleaning on stairs.
15. Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
16. Read and follow all label, operational and marking instructions.
17. Do not use charger with an extension cord. Plug charger directly into an electrical outlet. Use charger only in a standard (12OV-, 60Hz) electrical outlet.
18. Keep end of rotating brush, hose, wands and other openings away from your face and body.

    Do not use the cordless sweeper without dust container in place.

    Store the cordless sweeper indoors. Store after use to prevent accidents.
21. Leaks from battery cells can occur under extreme conditions. If the liquid, which is 20-35% solution of potassium hydroxide, gets on the skin - wash immediately with soap and water or neutralize with a mild acid such as lemon juice or vinegar. If the liquid aets into the eves. flush them immediatelv with clean water for a minimum of IO Minutes and seek medical attention.
22. Use only on dry, indoor surfaces.
23. Do not use for any purpose other than described in this user's guide.
24. Do not attempt to use the charger with any other product or attempt to charge this product with another charger. **Use only the charger model TechWorld AD-0920~UL supplied with this appliance.**

SAVE THESE INSTRUCTIONS

FOR HOUSEHOLD USE ONLY

Rev. 08/02B

CORDLESS SWEEPER

Model UV610
7.2 Volt DC



1. **Sweeper Power Head**
2. **On I Off Switch**
3. **Charging Light Indicator**
4. **Dust Cup (Container)**
5. **Rotating Brush**
6. **See Thru Brush Cover**
7. **Edging Tool**
6. **Charging Jack**
9. **Lower Handle**
10. **Metal Extension Handles**
11. **Upper Handle**
12. **Charging Adapter**
    (TechWorld AD-O920-UL rated output DCSV, 200mA.)

NOTE: **Cordless Sweeper Model UV610 is shipped with the batteries uncharged. Charging of the unit for 16-20 hours prior to first use is required.**

ASSEMBLING YOUR CORDLESS SWEEPER

Before you start:

Your Cordless Sweeper will require very little assembly. You should remove it from the carton and familiarize yourself with all the components listed per the exploded view drawing (pg.2) This will help you in the assembly and operation of your cordless sweeper

I. Insert the Edging Tool into the "square" hole under the bottom of the sweeper power head. Gently but firmly push until the edging tool locks into place.(See fig. 1)



Figure 1



Figure 2

2. Insert the lower handle - small end - into the sweeper power head. Push until firmly in place.(Fig. 2)

3. fissemble the metal extension handles by pushing the plastic insert into the mating metal tube. Push until only small portion of insert is visible or you cannot press any farther into the tubing. Push the handle assembly into the upper handle.(Fig. 3)
NOTE: **One metal extension tube has a different plastic insert. This tube should be on the bottom of the handle.**
Insert the handle assembly into the lower handle so that the "tab' on the plastic insert snaps into the open slot on the lower handle. (Fig. 3a)



Figure 3a

Figure 3

4. Place the handle into the upward storage position.

5. Plug the charging adapter into the sweeper power head charging jack. Plug the charging adapter cord into a standard electrical outlet (lZOV--,60Hz.)

HOW TO OPERATE YOUR CORDLESS SWEEPER

1. **Before using, please ensure that the cordless sweeper has been initially charged for 16-20 hours**
   Your cordless sweeper will only operate properly when the batteries are fully charged. When fully charged your sweeper will operate for 35-45 minutes - dependent upon the type of use (example - carpets or bare floors).
2. Push the On/Off switch to operate the unit. To turn off, press switch again(Fig.4)
   NOTE: Do not operate the sweeper without the dust container in place.



Figure 4

CAUTION: Any electronic or electrical appliance should not be stored or exposed to continued areas of high heat or humidity. Do not store your cordless sweeper close to stoves, radiators, furnaces or in a bathroom or bathing area.

3. To release the handle to a comfortable position, apply pressure to the top of the sweeper head with your foot while pulling back on the handle.(Fig. 5)

Figure 5

CLEANING THE DUST CONTAINER

To achieve the best performance, empty the dust container after each use.

I, Pull the dust container straight out from the side. (Fig. 6)



Figure 6

2. Empty dust container contents. (Fig. 7) If desired- you may rinse with water to clean the dust container - but **dry thoroughly** before replacing on the sweeper.



Figure 7

3 Replace dust container on cordless sweeper.

4. Periodically remove the “See Thru” cover on the front of the cordless sweeper and remove any build up of lint, hair or fiber on the rotating brush. To remove the cover - grip the cover from the bottom, pull out and upward until the cover unlocks from the side slots and tabs located on the top of the sweeper. (Fig. 8)



Figure 8

CAUTION: **Do not accidentally turn unit on while cleaning.** Do **not clean while unit is charging.**

CHARGING THE CORDLESS SWEEPER

I, Connect the charger plug to the charging jack or hole on the back of the sweeper. Plug the the charging adapter into the wall outlet. (120V-,60Hz.) Use only TechWorld Charger AD-092~UL, rated output DC9V,200mA. (Fig. 9)

2. This cordless sweeper is powered by Ni-Cd batteries. Before first use, they must be charged for a minimum of 16 hours.
3. Once the batteries are fully charged, the cordless sweeper will run for approximately 35 to 45 minutes before recharging is required.
4. When recharging the unit, the “On/Off’ switch must be in the “OFF” position.
5. To recharge, repeat step #I above. Charging times will vary depending upon the amount of usage between charging cycles.
6. The charging light indicator on the top of the sweeper will illuminate to indicate that the sweeper is properly charging.



Figure 9

NOTE: Peak performance may only be realized after the unit has been charged and discharged two (2) or three (3) times.

IMPORTANT: To maintain peak performance of your cordless sweeper, it is recommended that the unit be fully discharged, then completely re-charged at least once a month.

CAUTION

- Use only with the battery pack supplied with the unit.
- Do not attempt to remove the battery pack from the unit to charge it.
- Never attempt to throw the battery pack or unit into a fire or incinerate it.
- Do not attempt to remove or damage the battery casing.
- Battery must be recycled or disposed of properly at the end of it’s service life.

BATTERY REMOVAL & DISPOSAL

NOTE : If uncertain as to how to remove your battery pack, we suggest you take your vacuum cleaner to a reputable small appliance service technician to have this service performed.

Follow these steps when battery removal is required.

This vacuum cleaner is equipped with Ni-Cd batteries and you need to dispose of them properly. When the batteries are no longer good for use, they must be removed from the vacuum cleaner for disposal. Do not remove the batteries for any reason other than disposal of them. This vacuum cleaner contains nickel-cadmium Ni-Cd) batteries. The batteries must br recycled or disposed of properly. Call your nearest recycling center for information on the recycling and disposal of Ni-Cd batteries.

WARNING: **You** must never use ordinary batteries for replacement as these may leak and cause damage.

REMOVAL OF BATTERY PACK

1. Remove the extention handles and dust cup container.
2. Turn unit over so that the base is facing upwards. Remove See-Thru brush cover.
3. With a #I Phillips screwdiver, remove all ten (10) screws securing the base and the top housing.
4. Grasp the battery pack and remove both the red and black wires leading to the battery pack. The battery pack may now be removed.

CAUTION: This appliance contains Ni-Cd batteries. The batteries must be recycled or disposed of properly.

CARE AND MAINTENANCE

To improve the performance and **life of your unit, we recommend you do the following:**

1. Once a month clean the unit with a dry cloth, including the chamber which the dust container fits into. Remove any hair, fiber or other materials that may have built up in the chamber, on the rotating brush or edging tool.
2. Don't use abrasive materials to clean the sweeper. **Do not immerse the unit in water.**
3. Do not pick up liquids or use on wet floors.
4. Do not use on concrete, tar or similar rough surfaces.
5. Don't pick up pieces of string or fabrics with the sweeper.
6. Do not clean tasseled or frayed carpets with the sweeper.

TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE REASON	POSSIBLE SOLUTION
SWEEPER WILL NOT OPERATE	1. Batteries discharged. 2. No power in electrical outlet supplying transformer. 3. Unit needs servicing.	1 Charge unit. 2. Check fuse or breaker. Replace fuse/reset breaker 3 Call I-600-361 -4639.
SWEEPER WILL NOT PICK-UP OR SUCTION POWER IS WEAK	I. Dust container is full. 2. Unit needs recharging.	1. Empty dust container – 2. Charge unit.
DUST ESCAPING FROM SWEEPER	I. Dust container is full.	I. Empty dust container.
ROTATING BRUSH WILL NOT PICK UP	1. Unit clogged. 2. Dust container is full.	1. Check for excessive material on brush or In bottom of sweeper Remove obstruction from brushes and/or sweeper. 2. Empty and clean dust container.
SWEEPER WILL NOT CHARGE	1. Electrical outlet not working 2. Charging Adapter not working 3. Batteries no longer functioning	1. Check to ensure outlet is working properly. (Easily checked by plugging in another appliance. 2. Replace charging adapter 3. See disposal recommendations pg. 7.

EURO-PRO™

ONE (1) YEAR LIMITED WARRANTY

EURO-PRO CORPORATION warrants this product to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase, when utilized for normal household use, subject to the following conditions, exclusions and exceptions.

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, return the complete appliance and accessories, freight prepaid to ***EURO-PRO*** Corporation, 4400 Bois Franc, Ville St. Laurent, QC. H4S-IA7. If the appliance is found by ***EURO-PRO*** to be defective in material or workmanship, ***EURO-PRO*** will repair or replace it free of charge. Proof of purchase date and $ 11.95 to cover the cost of return shipping and handling must be included. *

Non-durable parts including, without limitation, dust cups, filters and brushes which normally require replacement are specifically excluded from warranty.

The liability of ***EURO-PRO*** Corporation is limited solely to the cost of the repair or replacement of the unit at our option. This warranty does not cover normal wear of parts and does not apply to any unit that has been tampered with or used for commercial purposes. This limited warranty does not cover damage caused by misuse, abuse, negligent handling or damage due to faulty packaging or mishandling in transit. This warranty does not cover damage or defects caused by or resulting from damages from shipping or repairs, service or alterations to the product or any of its parts, which have been performed by a repair person not authorized by ***EURO-PRO.***

This warranty is extended to the original purchaser of the unit and excludes all other legal and/or conventional warranties. The responsibility of ***EURO-PRO*** Corporation if any, is limited to the specific obligations expressly assumed by it under the terms of the limited warranty. **In no event** is ***EURO-PRO*** Corporation liable for incidental or consequential damages of any nature whatsoever, Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from province to province.

*iITlpOI%IfIt: Carefully pack item to avoid **damage** in shipping. Be sure to include proof of purchase date **and to attach tag to** item before packing with your name, complete address and phone number with a **note giving purchase information, model number and what you believe is the problem with item. We recommend you insure the package (as damage in shipping is not covered by your warranty). Mark the outside of your package "ATTENTION CUSTOMER SERVICE". We are** constantly **Striving to** improve our products, therefore the specifications contained herein are subject to change without notice.

✂ . . . . . .*.....

OWNERSHIP REGISTRATION CARD

Please fill out and mail the product registration card within ten (10) days of purchase in order to validate the foregoing Limited Warranty. The registration will enable us to contact you in the unlikely event of a product safety notification. By returning this card you acknowledge to have read and understood the instructions for use, and warnings set forth in the accompanying instructions.

RETURN TO ***EURO-PRO*** **CORPORATION: 4400 Bois Franc, Ville St. Laurent, QC, H4S-IA7**

UV610

Appliance model

Date purchased **Name of store**

Owner's name

Address **City** **Prov.** **Postal code**

Prtnted in China